



The **GREEN** way to Hone & Polish **MARBLE, TRAVERTINE & LIMESTONE**

Floor Machines 17" - 20" (175-350 rpm)

Pads remove wear and provide a variety of appearance levels from dull hone (no shine) to highly polished. Use on floors with little to no lippage (uneven tiles).

Instructions

Sweep or vacuum surface to remove abrasive soil
 Clean and rinse surface thoroughly prior to pad use
 Center selected pad on drive plate of floor machine
 Apply water to 2' x 5' area to lightly wet the surface - no need for huge puddles
 Move the floor machine in an oval pattern counter clockwise to keep the water inside the work area
 Check surface after 15 - 30 seconds to see if desired results are achieved
 If YES, repeat steps above on the rest of the floor one section at a time
 If NO, repeat polishing process until desired result is achieved (usually 15 - 45 seconds per 2' x 5' area)
 If second polishing does not achieve desired results, change pad grit level and repeat process

Hand Polishers 7" Variable Speed (600-3000 rpm)

Pads remove wear and provide a variety of appearance levels from dull hone (no shine) to highly polished. Use on floors, walls and counter tops with little to no lippage (uneven tiles).

Instructions

Dust or vacuum surface to remove abrasive soil
 Clean and rinse surface thoroughly prior to pad use
 Center selected pad on drive plate of hand polisher
 Apply water to 2' x 3' area to lightly wet the surface - no need for huge puddles
 At lowest speed setting, move the tool in an oval pattern counter clockwise to keep the water inside the work area
 Check surface after 15 - 30 seconds to see if desired results are achieved
 If YES, repeat steps above on the rest of the area one section at a time
 If NO, repeat polishing step until desired result is achieved (usually 15 - 45 seconds per 2' x 5' area)
 If second polishing does not achieve desired results, change pad grit level and repeat process

TIPS

- For best results with a 175 rpm Floor Machines use a 60 lb drive plate (not necessary for 300 - 350 rpm machines)
- Use more water when using lower grits (200 - 1,500)
- Use more weight (or pressure) and less water on higher grits (3,000 - 11,000)
- Overlap sections by 4"- 6" to keep an even appearance
- Rinse area thoroughly prior to changing grits
- Rinse and allow pad to dry after each use

Pads are color coded by grit level

200	400	800	1,500	3,000	8,000	11,000
DULL HONE	SMOOTH HONE	SATIN HONE	PRE POLISH	POLISH	SHINE	ULTRA SHINE



For questions or comments call 800-680-2046 or visit us online at www.EcoStoneSolutions.com
 15721 Bernardo Heights Pkwy #B308 San Diego, CA 92128